



Zehnder Salla Compact eWind

Installer manual



Table of Contents

| | | | | | |
|-----------|--|-----------|------------|---|-----------|
| 1. | Read first | 3 | 10. | Energy class | 23 |
| 2. | Type plate | 3 | 11. | Product information | 24 |
| 3. | Safety | 3 | 12. | Appendices | 25 |
| 3.1. | General information | 3 | 12.1. | Dimensional drawings | 25 |
| 3.2. | Electrical safety | 3 | 12.1.1. | Technical dimensional drawing, 4-duct right-handed | 25 |
| 4. | Contents of the delivery | 4 | 12.1.2. | Technical dimensional drawing, 4-duct left-handed | 26 |
| 4.1. | Available accessories | 4 | 12.1.3. | Technical dimensional drawing, 5-duct right-handed | 27 |
| 5. | Technical specifications of the unit | 5 | 12.1.4. | Technical dimensional drawing, 5-duct left-handed | 28 |
| 5.1. | Duct connections | 6 | 12.2. | Electrical diagrams | 29 |
| 5.2. | Checking the handedness in the type plate | 7 | 12.2.1. | Connections | 29 |
| 6. | Before installation | 7 | 13. | Record of measuring air amounts and sound levels | 31 |
| 6.1. | Choosing the installation location | 7 | 14. | Quick reference guide for the installer | 32 |
| 7. | Installation | 8 | | | |
| 7.1. | Wall installation without a bracket | 8 | | | |
| 7.2. | Ceiling installation | 9 | | | |
| 7.3. | Installation of the eWind control panel | 10 | | | |
| 7.4. | Installation of the Wifi module | 11 | | | |
| 7.5. | Installation to the Modbus bus | 12 | | | |
| 7.5.1. | Setting the Modbus parameters to the control system | 12 | | | |
| 8. | Commissioning | 13 | | | |
| 8.1. | Requirements | 13 | | | |
| 8.2. | Air flow adjustment | 13 | | | |
| 8.3. | Commissioning checklist | 13 | | | |
| 8.4. | Control system and the eWind operation panel | 14 | | | |
| 8.4.1. | Important information about the control system | 14 | | | |
| 8.4.2. | Setting the operational parameters | 14 | | | |
| 8.5. | Data display | 17 | | | |
| 8.5.1. | eWind info list | 17 | | | |
| 8.6. | Measurement display | 17 | | | |
| 8.6.1. | eWind measurement list | 17 | | | |
| 8.7. | Commissioning documentation | 18 | | | |
| 9. | Troubleshooting | 19 | | | |

All rights reserved

This documentation has been drafted with the greatest care. However, the publisher is not responsible for damages arising from omissions or errors in this documentation. In case of disputes, the Finnish version of the instructions will prevail.

1. Read first


This instruction manual is intended for all the persons involved in the installation of the Zehnder ventilation units. Only qualified professionals may install the equipment described in this manual in accordance with the instructions in this manual and the local laws and regulations. If the instructions provided in this manual are not followed, the warranty for the equipment becomes void and damages may be caused to persons or property.

The equipment described in this manual may not be used by persons (including children) with reduced physical, sensory or mental capacity or without sufficient experience or knowledge, unless a person responsible for their safety is supervising and advising them in the use of the equipment.

For your information

If the delivery does not contain all of the components listed in the section 'Contents of the delivery', please check the order and contact your distributor or Enervent before commencing installation.

2. Type plate



| | | | |
|------------------------|-------|---|-------|
| Enervent Zehnder Oy | | 10023631 | |
| Kipinätie 1 | | Salla Compact eWind | |
| FI-06150 PORVOO | | | |
| P022120002 | | | |
| CE | | | |
| 230 V | 4.2 A | 50 HZ | 750 W |
| | IP44 | | |
| Prod 29.08.2025 | | Serial-No. 004154448901 | |
| | |  | |

If you need technical support, please check the equipment type and serial number from the type plate.

The following pictograms are used:

| Symbol | Meaning |
|---|-------------------------|
|  | Important note |
|  | Risk of personal injury |

3. Safety

3.1. General information



Always check that the supply voltage to the equipment is switched off before opening the service hatch.



In case of a malfunction, always determine the reason for the malfunction before restarting the unit.



When you have switched off the power to the unit, wait for two (2) minutes before starting the maintenance work. Even though the power is switched off, the fans continue running and the post-heating coil remains hot for a while.

3.2. Electrical safety



Only an authorised electrician may open the electrical box.



Follow the local regulations on electrical installations.



Check that the unit is completely isolated from the mains supply before conducting any voltage tests, insulation resistance measurements or other electrical work or measurements. Such work may damage the sensitive electrical equipment.




Control equipment used in the ventilation units may cause leakage current. This may affect the operation of the residual current protection.



All ventilation units containing a control system must be equipped with an overvoltage protector.


4. Contents of the delivery



4.1. Available accessories


| Product number | Product name |
|----------------|--|
| 471011015 | Range hood Premium white |
| 471011045 | eWind controller. The package contains a controller, surface mounting box and a 10-metre cable |
| 471010975 | CO2 carbon dioxide transmitter for the room 0-10 V/24 V |
| 471010974 | %RH humidity transmitter 0-10 V/24 V |
| 471010264 | Humidity transmitter duct mounted KLK100 |
| 471011048 | Overpressure push button 'fireplace switch'/boost |
| 471010382 | KNX bus adapter |
| 471010997 | Water trap Enervent Salla Compact |

5. Technical specifications of the unit




| | |
|--|---|
| Width | 580 mm |
| Depth | 498 mm |
| Height | 483 mm |
| Weight | 55 kg |
| Duct connection (duct size) | Ø 160 mm |
| Duct connection (duct size) CHC | Ø 125 mm |
| Range hood connection (duct size) CHC | Ø 100 mm |
| Fans | supply 118 W, 1.0 A; exhaust 118 W, 1.0 A |
| Heat exchanger motor with thermal protection | 5 W, 0.04 A |
| Power of electric post-heating coil in E-models | 400 W/230 V, 1~/50 Hz/1.74 A |
| Input power, E-model (post-heating coil) | 641 W/230 V, 1~/50 Hz/3.78 A |
| Circuit breaker | B10 A |
| Mains supply | 230 V, 1~/50 Hz/10 A |


5.1. Duct connections




right-handed 4-duct



left-handed 4-duct







right-handed 5-duct



left-handed 5-duct

5.2. Checking the handedness in the type plate



6. Before installation

6.1. Choosing the installation location


-  Ensure that the ventilation system has been designed and realised in accordance with the building regulations.
-  We recommend that the unit be installed in the technical facility.
-  Do not install the unit in a room where the temperature and humidity are high. Under certain conditions, condensation may occur on the outer surface of the unit.
-  Take the noise level of the unit into account when choosing the installation location.
-  Install the unit on a soundproof wall, if possible.
-  Do not install the ventilation unit directly outside the bedroom, as the unit is never completely silent, although it is quiet.
-  Install an insulation plate behind the ventilation unit, or try to prevent the sound from being conducted to the structure by other means. Using soft foam sheets is recommended (not included in the delivery).

 Ensure that connecting the condensation water discharge pipe and water trap is possible. Remember to take the space required by the condensation water connection into account.

 Install the unit in a warm room (over +5°C).

 Ensure that at least 500 mm of free space is left in front of and at least 80 mm of free space is left below the unit for maintenance purposes.

In case the cooker hood connection is going to be used then the plug must be removed first.









Would you like to know more?

If you would like to know more about the construction of ventilation systems and the insulation of ventilation ducts, you can read about them on our website at www.enervent.com.







7. Installation

7.1. Wall installation

For your information
Check before the installation of the ventilation unit that there are no foreign objects in the ventilation unit or ductwork.





7.2. Ceiling installation




7.3. Installation of the eWind control panel

The eWind control panel (see section 'Control system and the eWind operation panel' on page 87) is installed in a wall-mounted device box or using the surface-mounting box supplied with the accessory delivery. No more than two external control panels can be installed in the ventilation unit.





7.4. Installation of the Wifi module



7.5. Installation to the Modbus bus



The ventilation unit can also be controlled via the Modbus connector X26.

Modbus specification:

- Modbus address 1 (default)
- Data transmission protocol RS485
- Modbus traffic via the motherboard's Modbus connector X26
- Speed 9,600, 19,200 or 115,200 bps
- 8-bit
- No parity or parity

The order of the poles in the Freeway connector is marked in the controller board.

The Modbus registers are available on the Enervent website at www.enervent.com.



Caution!
Do not connect an external bus to the motherboard before the bus has been programmed and is compatible with the control of the unit.

7.5.1. Setting the Modbus parameters to the control system

1. Simultaneously press the buttons and three times in the control panel.
2. Using buttons and , choose the parameters c31-c32. The meaning of each parameter is described in section 'Parameter list' on page 14.
3. Select the parameter to be adjusted by pressing button for 3 seconds.
4. Change the parameter value using buttons and .
5. Confirm the value by pressing button .
6. Exit the settings by simultaneously pressing buttons and .

8. Commissioning

8.1. Requirements

Operational requirements for the ventilation unit:

- Supply and exhaust air temperature below +55°C.
- Exhaust air temperature at least +10°C
- Supply air temperature for heat recovery over +5°C
- Supply air temperature over +10°C
- All foreign objects have been removed from the ventilation system
- Both fans are running

8.2. Air flow adjustment

When the unit has been switched on, the air flows must be adjusted to the designed values.

- The air flows are adjusted in connection with the commissioning of the ventilation unit.
- **The adjustment is made separately for both fans in each operation mode (= at each fan speed).**

Check the following during the adjustment:

- All filters are clean.
- All supply and extract air vents, the roof inlet, and the outdoor air grilles are in place.

For your information

Do not cover the outdoor air grille with a mosquito net.


To achieve optimum adjustment values, the air flows must be measured at each duct opening. A suitable measurement device is a thermoanemometer or a differential pressure gauge. With the aid of the measurement values, the air flow can be adjusted to match the design values.

A correctly adjusted ventilation unit is quiet and provides a good thermal economy. In addition, it also maintains a slight negative pressure in the house. The negative pressure prevents humidity from entering the walls and ceiling.

8.3. Commissioning checklist

| Measure | Inspected | Notes |
|---|-----------|-------|
| The unit has been installed in accordance with the installation instructions provided by the manufacturer. | | |
| The condensation water discharge pipe has been connected to the water trap, and its operation has been tested. | | |
| Silencers have been installed in the supply and extract air ducts. | | |
| The terminal devices have been connected to the ductwork. | | |
| An outdoor air grille has been installed for the intake of fresh air. NOTE: Do not cover the grille with a mosquito net. It makes cleaning difficult. | | |
| The unit has been connected to an appropriate power supply. | | |
| The ventilation ducts have been insulated in accordance with the ventilation plan. | | |
| The airflows are adjusted according to the ventilation plan. | | |

8.4. Control system and the eWind operation panel



1. Mode (standard display)

2. Temperature (standard display)

3. Mode button

4. Eco button

5. Temperature button

6. Cable connection

8.4.1. Important information about the control system

The factory settings are suitable for most installations.

The fan speed settings for various operating modes are installation specific, and they must be specified and set separately in connection with each installation. In other cases, the factory setting must not be changed unless otherwise instructed in the ventilation system plan.

Make sure that all necessary information is available before starting to adjust the settings.

8.4.2. Setting the operational parameters

The fan speed settings for different operation modes must be specified and set separately in connection with each installation. The settings are described in the parameter table.

1. Simultaneously press buttons  and  three times.
2. Using buttons  and , choose the parameters c1-c32. The meaning of each parameter is described in section 'Parameter list' on page 16.
3. Select the parameter to be adjusted by pressing button  for 3 seconds.
4. Change the parameter value using buttons  and .
5. Confirm the value and return to the selection of parameters c1-c32 by pressing button .
6. Exit the settings by simultaneously pressing buttons  and .

Parameter list

| Parameter | Description | Factory setting | Note | Modbus register | Field setting |
|-----------|---|-----------------|--|-----------------|---------------|
| C1 | Extract fan speed, mode 1, region: 20–100%, step: 1% | 36% | 'Away' mode | 102 | |
| C2 | Supply fan speed, mode 1, control range: 20–100%, step: 1% | 35% | 'Away' mode | 100 | |
| C3 | Extract fan speed, mode 2, control range: 20–100%, step: 1% | 56% | Home mode | 52 | |
| C4 | Supply fan speed, mode 2, control range: 20–100%, step: 1% | 55% | Home mode | 51 | |
| C5 | Extract fan speed, mode 3, control range: 20–100%, step: 1% | 83% | Maximum power also in the removal of humidity and carbon dioxide | 74 | |
| C6 | Supply fan speed, mode 3, control range: 20–100%, step: 1% | 80% | Maximum power also in the removal of humidity and carbon dioxide | 72 | |
| C7 | Extract fan speed, mode 4, control range: 20–100%, step: 1% | 100% | Manual boosting | 68 | |
| C8 | Supply fan speed, mode 4, control range: 20–100%, step: 1% | 100% | Manual boosting | 67 | |
| C9 | Time limit for manual boosting (mode 4), control range: 0–4 h, step: 1 h | 2 h | Setting the time limit 0 h prevents the use of mode 4 and activates the 3-speed external control | 66 | |
| C10 | Extract fan speed, fireplace/range hood mode, control range: 20–100%, step: 1% | 30% | | 55 | |
| C11 | Supply fan speed, fireplace/range hood mode, control range: 20–100%, step: 1% | 50% | | 54 | |
| C12 | Time limit for fireplace mode/selection of range hood, control range: 0–15 min, step: 1 min | 10 min | Setting time limit 0 min replaces the fireplace mode with the range hood mode. | 56 | |
| C13 | Heat recovery defrosting, on/off | Off | | Coil 55 | |
| C14 | Maintenance reminder interval 4 or 6 months | 4 | Register value in days | 538 | |
| C15 | CHG/AGH pre-heating and AGH precooling, on/off | On | | Coil 58 | |
| C16 | CHG/AGH outdoor temperature TE01, below which pre-heating is used, control range: 0–10°C, step 1°C (for pre-heating) | 5°C | | 592 | |
| C17 | CHG/AGH pre-heating is not in use when the outdoor air temperature (TE01) rises above value (c16) + (c17), control range: 1–5°C, step 1°C | 1°C | | 593 | |
| C18 | CG cooling or CHG pre-cooling, on/off | On | Applies to CG and CHG heat exchangers | Coil 52 | |

Parameter list

| Parameter | Description | Factory setting | Note | Modbus register | Field setting |
|------------|---|-----------------|---|-----------------|---------------|
| C19 | Outdoor temperature TE01, above which pre-cooling/cooling is allowed | 17°C | | 164 | |
| C20 | AGH outdoor temperature, above which the earth duct is used, control range: 15–25°C, step 1°C, (for pre-cooling) | 20°C | | 629 | |
| C21 | AGH pre-cooling is not in use when the outdoor air temperature (TE01) drops below value (c20-c21), control range: 1–5°C, step 1°C | 2°C | | 630 | |
| C22 | Temperature setting for air temperature after the electric pre-heating, control range: –10...–20°C, step: 1°C | –15°C | | 591 | |
| C23 | Boosted operation for the removal for humidity, on/off | On | | Coil 19 | |
| C24 | Threshold value for summer/winter temperature, control range –10...+10°C, step 1°C | 4°C | The 24-hour average temperature of the outdoor air. Above the threshold value, the boosted operation for the removal humidity is in the summer mode, and below the threshold value, it is in the winter mode. | 137 | |
| C25 | Threshold value for dehumidification, control range 10–100 %RH, step 5% | 45% | In the winter mode, the boosted operation for the removal of humidity starts when the humidity value exceeds the threshold value. | 69 | |
| C26 | Threshold value for starting dehumidification, control range: 5–30%, humidity exceeds the 48-hour average value, step 5% | 15% | In the summer mode, the boosted operation for the removal of humidity starts when the relative humidity exceeds the 48-hour average value of humidity by the amount of the threshold value. | 70 | |
| C27 | Boosted operation for the removal of carbon dioxide, on/off | Off | | Coil 21 | |
| C28 | Threshold value for starting the carbon dioxide removal, control range: 600–1,200 ppm, step: 100 ppm | 1,000 ppm | | 76 | |
| C29 | Boosted operation for the removal of humidity with the rotating heat exchanger, on/off | Off | | Coil 24 | |
| C30 | Display dimmed in the standby mode, on/off | Off | Panel-specific setting off: dark display in the standby mode, on: dimmed display in the standby mode. | Internal | |
| C31 | Modbus address of the automation motherboard, control range: 1–99, step: 1 | 1 | | 640 | |
| C32 | Modbus bus speed, 1 = 9,600, 2 = 19,200, 3 = 115,200 | 2 | 19,200 bps | 733 | |

8.5. Data display

You can view the available functions in the eWind info list on the data display.

8.5.1. eWind info list

Opening:

1. Simultaneously press buttons  and  once. Parameter (n1..nn) is displayed.

2. Browse the info list using buttons  and .

Return to the standard view:

3. Simultaneously press buttons  and  once.

For your information

If you do not press any button, the menu will close in 5 minutes and the panel will return to the standard view.

8.6. Measurement display

You can monitor temperature, humidity, heat recovery efficiency and other measurement values in the eWind measurement list, which is displayed on the measurement display.

| eWind info list | |
|-----------------|--|
| Marking | Definition |
| n0 | Standard mode is on |
| n1 | Boosted ventilation for the removal of humidity |
| n2 | Boosted ventilation for the removal of carbon dioxide |
| n3 | Heat recovery is on |
| n4 | Post-heating with an electric or water coil is on |
| n5 | Outdoor air pre-heating with CHG/AGH or an electric pre-heater is on |
| n6 | Supply air CG, CHG, or AGH cooling is on |
| n7 | Cold recovery with the rotating heat exchanger is on |
| n8 | Ventilation boosted manually |
| n9 | Away mode is on |
| n10 | Dehumidification with rotor is on |
| n11 | Defrosting is on |
| n12 | Eco mode is on |
| n13 | Maintenance reminder: the time remaining until the next filter replacement in days |
| n14 | Unit is starting |

8.6.1. eWind measurement list

Opening:

1. Simultaneously press buttons  and  two times. Parameter (r1..rn) and the parameter values are displayed.

2. Browse the parameter list up or down by pressing button  or .

Return to the standard view:

3. Simultaneously press buttons  and  once.

eWind measurement list

| Marking | Definition | Marking in the chart and the connection in the automation motherboard | Note | Modbus register |
|---------|---|---|---|-----------------|
| r1 | Outdoor air temperature, °C | TE01 | All models | 6 |
| r2 | Supply air temperature after heat recovery, °C | TE05 | All models | 7 |
| r3 | Supply air temperature, °C | TE10 | All models | 8 |
| r4 | Extract air temperature, °C | TE30 | All models | 10 |
| r5 | Exhaust air temperature, °C | TE32 | All models | 9 |
| r6 | Return water temperature of water-based heating coil, °C | TE45 | eWind W only. Other models display '0'. | 12 |
| r7 | Temperature of pre-heated outdoor air (CHG/AGH/electric pre-heater), °C | TE02 | Only if equipped with CHG/AGH or an electric pre-heater. | 32 |
| r8 | Relative humidity (RH) of exhaust air | RH30 | All models | 13 |
| r9 | Carbon dioxide level, ppm | | Without an external carbon dioxide sensor (accessory), '- -' is displayed | 23 |
| r10 | Measurement of external relative humidity, %RH | | Without an external humidity sensor (accessory), '- -' is displayed- | 23 |
| r11 | Temperature efficiency of the supply air heat recovery, % | | All models Calculated value | 29 |
| r12 | Temperature efficiency of the exhaust air heat recovery, % | | All models Calculated value | 30 |

8.7. Commissioning documentation

- Fill in the warranty information.
- Fill in the air volume measurement document.

For your information

The warranty is not valid for units with no documented air volume measurement.

It is extremely important to record all the changes made to the parameters. This ensures that there are backup copies of the information in case the automation is damaged (e.g., by a lightning strike).

9. Troubleshooting

| Problem | Reason | Help | Solution |
|--|--|--|---|
| FILS Service reminder | Regular reminder with 6 month interval (depending on unit model) | | Change the filters and clean the unit from the inside and check if the unit is working. |
| Err Temperature sensor malfunction | The temperature sensor is short-circuited or there is a break in the connection. | | Turn off the ventilation unit from the main switch, open the electrical box, and check that the quick couplings of the temperature sensors are connected. It is possible that the quick connectors have come loose during the installation of the unit. Contact a service representative. |
| oFFE Stop mode | The internal alarm of the heat pump unit is active. | | Find out the status of the external control system. Contact a service representative. |
| AL1 The water heating coil is starting to freeze. NOTE! The ventilation unit does not start until the alarm state has been removed and the alarm has been reset by pressing any button on the control panel. | The heat exchanger belt has broken. | The heat exchanger has a green belt. Check the heat exchanger rotor from the belt's control hole. If the belt is not visible, it is broken. | Change the belt. |
| | The heat exchanger belt-wheel is oily and the belt is slipping | The heat exchanger has a green belt. Check the heat exchanger's rotor from the belt's control hole if the belt wheel is rotating even if the heat exchanger rotor is not rotating. | Change the belt. |
| | The exhaust fan has stopped. | Open the service hatch when the unit is running. The exhaust fan needs to be on. With the LTR unit you must push down the door coupling with a screwdriver and check if the unit starts. | Change the fans. Contact a service representative. |
| | The exhaust filter is clogged. | Open the service hatch when the unit is not on. Remove the filters and check if they are dirty. | Change the filters. |
| | The water heater's valve actuator is broken. | | Contact a service representative. |
| | The circulating water pump has stopped. | Check if the heating/cooling circulation pump is on. | Start the pump, contact a service representative if the problem persists. |
| | Error in the heat exchanger motor/gearbox | Open the service hatch while the unit is on and listen if the noise is coming from the heat exchanger. | Contact a service representative. |
| | The heat exchanger belt wheel has come loose from the axle. | Check the heat exchanger rotor from the belt control hole if the axle is rotating freely and the belt wheel is stationary. | Tighten the belt wheel screw. Contact a service representative. |

| Problem | Reason | Help | Solution |
|---|--|--|--|
| AL2 Supply air is cold after the rotary heat exchanger. | The heat exchanger belt has broken. | The heat exchanger has a green belt. Check the heat exchanger rotor from the belt's control hole. If the belt is not visible, it is broken. | Change the belt. |
| | The heat exchanger belt-wheel is oily and the belt is slipping | The heat exchanger has a green belt. Check the heat exchanger's rotor from the belt's control hole if the belt wheel is rotating even if the heat exchanger rotor is not rotating. | Change the belt. |
| | Error in the heat exchanger motor/gearbox | Open the service hatch while the unit is on and listen if the noise is coming from the heat exchanger. | Contact a service representative. |
| AL3 Supply air is cold | The exhaust fan has stopped. | Open the service hatch when the unit is running. The exhaust fan needs to be on. With the LTR unit you must push down the door coupling with a screwdriver and check if the unit starts. | Change the fans. |
| | The exhaust filter is clogged. | Open the service hatch when the unit is not on. Remove the filters and check if they are dirty. | Change the filters. |
| | The ventilation unit runs with a too low fan speed. | The correct fan speed was chosen when the ventilation was balanced in your house. Check your ventilation installation sheet for the correct fan speeds. | Adjust the fan speed from the control panel. Contact a service representative. |
| | The ventilation is adjusted incorrectly. | | Contact the company that has installed your ventilation unit and check if the house's airflow/valves has been adjusted correctly. Contact a service representative. |
| AL4 Supply fan malfunction | The supply air fan has stopped | Open the service hatch when the unit is running. The exhaust fan needs to be on. With the LTR unit you must push down the door coupling with a screwdriver and check if the unit starts. | Contact a service representative. |
| AL5 Extract fan malfunction | The exhaust fan has stopped. | Open the service hatch when the unit is running. The exhaust fan needs to be on. With the LTR unit you must push down the door coupling with a screwdriver and check if the unit starts. | Change the fans. Contact a service representative. |

| Problem | Reason | Help | Solution |
|---|--|--|--|
| AL6 The water heating coil is starting to freeze. NOTE! The ventilation unit does not start until the alarm state has been removed and the alarm has been reset by pressing any button on the control panel. | Insufficient isolation in the ducts. | | Check the thickness of the insulation in the supply air and the exhaust air ducts and improve the insulation when required. Contact a service representative. |
| | The overheating protection of the afterheater has been activated | | Find out what has caused the error and reset the over-heating protection (® button on the coil) Contact a service representative. |
| | The ventilation unit's door is open | | Close the door. Contact a service representative. |
| | Low room temperature | | Raise the room temperature. Contact a service representative. |
| | TE-30 error in the temperature sensor | | Contact a service representative. |
| AL7 Supply air hot. Risk of fire. | Error in the electrical after heater | | Contact a service representative. |
| | The water heater's valve actuator is broken | | Contact a service representative. |
| | TE-10 error in the temperature sensor | | Contact a service representative. |
| | Fire risk | | Contact a service representative. |
| AL8 Electrical re-heater or pre-heater overheating | Error in the electrical after heater | | Contact a service representative. |
| | The supply air fan has stopped | Open the service hatch when the unit is running. The exhaust fan needs to be on. With the LTR unit you must push down the door coupling with a screwdriver and check if the unit starts. | Contact a service representative. |
| | The supply air filter is clogged | Open the service hatch when the unit is not on. Remove the filters and check if they are dirty. | Change the filters. |
| | The outside air grille is clogged | Check if there is something blocking the outside air grille. | Clean the outdoor air grille Contact a service representative. |
| | The heater controller card is broken | | Replace the heater controller card Contact a service representative. |

EU DECLARATION OF CONFORMITY

We declare that our products follows the provisions of low voltage directive LVD 2014/35/EU, electromagnetic compatibility directive EMC 2014/30/EU, radio equipment directive RED 2014/53/EU, machine directive MD 2006/42/EC, ROHS II directive 2011/65/EU and waste electrical and electronic equipment directive WEEE 2012/19/EU.

Manufacturer: Enervent Zehnder Oy
Manufacturer's contact: Kipinätie 1, 06150 Porvoo, FINLAND,
tel. +358 207 528 800, fax +358 207 528 844
enervent@enervent.com, www.enervent.com

Description of the product: Ventilation unit with heat recovery

Trade name of the product: Salla Compact eWind E right, Salla Compact eWind E left

The products are in conformity with the following standards:

LVD EN 60335-1:2012/A15:2021
EN 62233:2008/AC:2008

EMC EN 61000-3-2:2014 and EN 61000-3-3:2013
EN 61000-6-1:2007 and EN 61000-6-3:2007/A1:2011/AC:2012

RED EN 300328 v2.2.2

MD EN ISO 12100:2010

ROHS EN IEC 63000:2018

The conformity of each manufactured product is taken care according our quality descriptions.

Product is CE-marked year 2026


Porvoo 2nd of January 2026

Enervent Zehnder Oy



Tom Palmgren
Technology manager

10. Energy class



11. Product information

Product information according to EU commission regulation no 1253/2014 and 1254/2014


| | |
|--|---|
| Supplier's name or trade mark | Enervent Zehnder |
| Supplier's model identifier | Salla Compact |
| Specific energy consumption (sec) in kWh/(m ² .A) | |
| - Cold climate | -84,50 |
| - Average climate | -40,81 |
| - Warm climate | -15,78 |
| Declared typology in accordance with article 2 of this regulation | RVU / BVU |
| Type of drive installed or intended to be installed | Multi-speed drive |
| Type of heat recovery system | Regenerative |
| Thermal efficiency of heat recovery | 84,0 |
| Maximum flow rate in m ³ /h | 374 |
| Electric power input of the fan drive, including any motor control equipment, at maximum flow rate (W) | 211 |
| Sound power level (L _{WA}), rounded to the nearest integer | 40 |
| Reference flow rate in m ³ /s | 0,073 |
| Reference pressure difference in Pa | 50 |
| SPI in W/(m ³ /h) | 0,37 |
| Control factor and control typology in accordance with the relevant definitions and classification in annex VIII, table 1 | 0,65 |
| Declared maximum internal and external leakage rates (%) for bidirectional ventilation units | <4% / <2% |
| Position and description of visual filter warning for rvus intended for use with filters, including text pointing out the importance of regular filter changes for performance and energy efficiency of the unit | Filter warning on control panel. Instructions in user manual. |
| Internet address for disassembly instructions as referred to in point 3 | https://doc.enervent.com/op/op.ViewOnline.php?documentid=3067&version=0 |
| The annual electricity consumption (AEC) (in kWh electricity/a) | 195 |
| The annual heating saved (AHS) (in kWh primary energy/a) for each type of climate | |
| - Cold climate | 8938 |
| - Average climate | 4569 |
| - Warm climate | 2066 |

The information on the energy label for this product has been defined with local demand control. Local demand control means that the ventilation unit continuously regulates the fan speed(s) and flow rates based on more than one sensor. Please remember to connect all local sensors (some sold as extra equipment) in order to achieve the declared energy class.

12. Appendices

12.1. Dimensional drawings

12.1.1. Technical dimensional drawing, 4-duct right-handed




12.1.2. Technical dimensional drawing, 4-duct left-handed

| | | |
|--|--|------------------------------|
| Item Quantity | Title/Name , designation, material, dimension etc | Article no./Reference |
| Designed by | Approved by | Date |
| Checked by | Filename | Scale |
| SALLA COMPACT left Ø160 | | Weight kg |
| Dimension Drawing | | Edition Sheet |
| Drawing number P18_004_005 | | Revision note |
| Enervent Oy, enervent@enerventgroup.com Tel. +358 207 528 800, www.enervent.com Kipinlehtie 1, FIN-00150, Porvoo | | |

| | | | |
|--|---|---|--|
| 1 ULKOILMA UTELUFT UTELUFT OUTSIDE AIR | 2 TULOILMA TILLUFT TILLUFT SUPPLY AIR | 3 POISTOILMA FRÄNLUFT AVTREKK EXTRACT AIR | 4 JÄTEILMA AVLUFT AVKAST EXHAUST AIR |
|--|---|---|--|



12.1.3. Technical dimensional drawing, 5-duct right-handed






| | | | |
|--|---------------------------------|--|--------------------------|
| Item | Quantity | Title/Name, designation, material, dimension etc | Article no./Reference |
| Designed by | Checked by | Approved by | Date |
| SALLA COMPACT right Ø125 DIMENSION DRAWING | | Filename | Scale |
| Title/Name | | Weight kg | Edition |
| Drawing number | | 004 | 002 |
| Envent Oy, envent@zandergroup.com Tel. +358 207 528 500, www.envent.com Kipinatie 1, FIN-06150, Porvoo | | | |
| Yleistoleranssit | | Hitsatut rakenteet: EN ISO 13920-AE Koneistetut osat: ISO 2768-MK | |
| 1 | ULKOILMA UTELUFT UTELUFT | 2 | TULOILMA TILLUFT TILLUFT |
| 3 | POISTOILMA FRÄNLUFT AVTREKK | 4 | JÄTEILMA AVLUFT AVKAST |
| 5 | LIESIKUPU SPISKÅPA KJØKKENHETTE | COOKER HOOD | |
| Rev | Revision note | Date | Signature/Checked |

| Name | Definition | Marking on the circuit board |
|--------------------------|--|------------------------------|
| FP/EX | Fireplace/Range hood mode | DI6 |
| AWAY | Away mode | DI5 |
| BOOST | Manual boosting | DI4 |
| ESTOP | Emergency stop | DI1 |
| TE45 | Return water temperature sensor eWind W models | TE45 |
| TE46 | Return water temperature sensor eWind CG models | TE45 |
| TE02 | Pre-heated outdoor air temperature, external pre-heater | TE02 |
| TE20 | Return air temperature ((KOTILÄMPÖ eWind) | TE02 |
| TE10 | Supply air temperature | TE10 |
| TE01 | Outdoor air temperature | TE01 |
| RH CO₂ | External humidity sensor as default (RH 0–100%). If parameter c27 is active, CO ₂ sensor (200–2,000 ppm) (accessory) | AI1 |
| TL01 TL50 | Pre-heating actuator, CHG models. Cooling actuator, CG models | AO6 |
| TL45 | Heating actuator, W models | AO5 |
| DO8 | Alarm output A as default pre-heating on/off control, CHG –AGH, electric pre-heater models cooling on/off control, CG models, condensate tray heater | DO8 |
| DO5 | Outdoor air and extract air damper control (accessory) | DO5 |
| DO2 | Heating on/off control eWind models MAX 500-W PUMP | DO2 |
| OP1 | Control panel with 10m cable (additional equipment) | OP1 |
| OP2 | Control panel with 10m cable (additional equipment) | OP2 |

14. Quick reference guide for the installer



| | | | | | | | | |
|------------|--|-----------------------------|------------|--|---|------------|-------------------------|---|
| C1 | | 36% (20-100%) | C12 | | 10 min (5...15 min) | C23 | | on (on / oFF) |
| C2 | | 35% (20-100%) | C13 | | oFF (on / oFF) | C24 | | 4°C (-10...+10°C) |
| C3 | | 56% (20-100%) | C14 | | 4 (4 / 6) | C25 | | 45% (10...100%RH) |
| C4 | | 55% (20-100%) | C15 | | oFF (on / oFF) | C26 | | =>on, 48 h %RH + c26, 15% (5...30%) |
| C5 | | 83% (20-100%) | C16 | | => on, TE01 < °C, 5°C (0...10°C) | C27 | | oFF (on / oFF) |
| C6 | | 80% (20-100%) | C17 | | => off, TE01 > (c16 + c17), 1°C (1...5°C) | C28 | | CO2=> on, 1000 ppm (600...1200) |
| C7 | | 100% (20-100%) (120 min) | C18 | | on on / oFF | C29 | | oFF (on / oFF) |
| C8 | | 100% (20-100%) (120 min) | C19 | | => on, TE01 > °C, 17°C | C30 | | oFF (on / oFF) |
| C9 | | 2 h (1...4 h) | C20 | | => on, TE01 > °C, 20°C (15...25°C) | C31 | eWind Modbus | 1 (1...99) |
| C10 | | 30% (20-100%) | C21 | | => off, TE01 < (c20 - c21), 2°C (1...5°C) | C32 | Modbus | 2 (1=9600, 2=19200, 3=115200) |
| C11 | | 50% (20-100%) | C22 | | -15°C (-10...-20°C) | | | |



- r1 °C TE01
- r2 °C TE05
- r3 °C TE10
- r4 °C TE30
- r5 °C TE32
- r6 °C TE45
- r7 °C TE02
- r8 %RH RH30
- r9 %CO2
- r10 °C
- r11 °C
- r12 η%

